

# MB2300-1 External Blast Timer

The MB2300-1 External Blast Timer is an option that increases the efficiency of your blasting operation by providing repeatability of the process.

In manual blasting applications, the operator controls the length of the blasting time. With the MB2300-1, the timer controls the blast duration, thereby eliminating operator variations that may occur in manual use. If the duration of each blast is crucial to your process, the External Blast Timer provides you with the solution!

- ❑ Offers a wide range of blast times
- ❑ Easily changes from timed mode to manual mode



Connecting the MB2300-1 does not require any tools. The footswitch is connected to the back of the timer box and the MB2300-1 plugs into the footswitch receptacle on the back of the blaster.



Setting the length of the blast time is also simple. All of the adjustment selectors are located on the front of the timer and are easily accessible to the operator. The timer can be set to blast from less than 1 second to over 60 minutes. Once the timer is set, depressing the blaster footswitch activates the blast cycle for only the preset period of time. When blasting with the timer is not desired, the operator simply resets the timer to zero to restore the blast cycle to manual mode.

Once the timer is set, depressing the blaster footswitch activates the blast cycle for only the preset period of time. When blasting with the timer is not desired, the operator simply resets the timer to zero to restore the blast cycle to manual mode.

**The MB2300-1 External Blast Timer is designed to integrate with any Comco AccuFlo®, DirectFlo™, or PowerFlo® model micro-abrasive blaster.**

Call us today to find out more about how the MB2300-1 External Blast Timer can provide your process with increased control and a higher degree of repeatability!



COMCO INC. 2151 N. Lincoln St. / Burbank, CA 91504  
818-841-5500 / 800-796-6626 / [www.comcoinc.com](http://www.comcoinc.com)